

SILo WIRELESS REMOTE INSTALLATION



STEP 1

Unbox the silo remote Package.



STEP 2

Remove adhesive film cover from the reciever.



STEP 3

Install recievers adhesive side against side wall beside timer inside battery box.



STEP 4

Connect positive and negative wires to battery .
Make sure red wire is connected to positive and black wire to negative.



STEP 5

Find the pre wired plug in, at existing wire harness **Will have tag.**



STEP 6

Disconnect plug cap from pre wired harness.



STEP 7

Connect the silo remote plug into the pre wired harness.



STEP 8

Connect antenna to reciever....
Note keep antenna inside feeder battery compartment.



STEP 9

Use hand held remote to operate.... **Slide side button up to turn on frequency .**



STEP 10

Press on and off button to operate feeder.