

CLEANING INSTRUCTIONS FOR PRIMEALUX OUTDOOR PRODUCTS

To keep PrimeAlux products durable and attractive for years, certain cleaning tips will help keep them in mint condition. Regular cleaning removes dirt and stains from the product's surface, maintaining the coating's aesthetic appearance.

In areas near saltwater or high pollution, stains may accumulate on the coating's surface, potentially leading to gradual fading. This can accelerate degradation due to corrosion, ultimately reducing the coating's lifespan.



Documented cleaning must be performed at least twice a year, with increased frequency in harsher weather conditions. Cleaning should be avoided when temperatures exceed 30°C/86°F to prevent potential damage to the surface.

2222 South Sheridan Way, Unit 116, L5J2M4, Mississauga, ON, Canada

The cleaning process for PrimAlux products is quick and easy. However, the following points have to be considered while cleaning:

1- Rinse down your PrimeAlux product

The best way to begin is by thoroughly rinsing the product with a garden hose. Make sure all soil, leaves, and debris are washed away. Keeping the product wet with a light drizzle of water or washing in the early evening helps prevent spots from forming. Always use an indirect spray rather than a high-pressure jet.

- **Do not** use water jets or high-pressure water jets.
- **Do not** wash in direct sunlight, as heat can cause water and soap to dry too quickly, leaving spots on the surface.

2- Use a soft microfiber cloth

A microfiber drying towel is softer and more absorbent than other household towels, which will protect your finish from scratches and dry your product more quickly.

- **Do not** use a sponge to wipe away any remaining dirt, dust, or other matter.
- **Do not** rub the profiles too hard, as this may scratch the finish.
- **Do not** use household towels made of polyester, as they are too abrasive for the surface.

3- Start at the bottom

Always start cleaning from the bottom and work your way up. This is important because you don't want to collect dirty run-off water along the way. As you clean upward, the finish may start to look streaky. To fix this problem, simply mix your non-abrasive cleaner with water, apply it to the entire product, wait about 30 seconds, then continue moving upward.

PrimeAlux LTD,